


Q. How do you set up the Parking Lot Feature in your PBX?

1. In your PBX admin portal select “Parking Lot” from your options on the left hand side.

A screenshot of the "Parking Lot Options" configuration page. The page has a title bar "Parking Lot Options" and a red horizontal line below it. The configuration options are: "Enable Parking Lot Feature" with a checked checkbox (labeled with a red "2"); "Parking Lot Extension:" with a text input field containing "500" (labeled with a red "3"); "Number of Slots:" with a dropdown menu showing "8" (labeled with a red "4"); "Parking Timeout:" with a dropdown menu showing "1 minute, 30 seconds" (labeled with a red "5"); and "Parking Lot Context:" with a text input field containing "parkedcalls" (crossed out with a red X).

2. Click the check box to “Enable Parking Lot Feature”.
3. Choose the extension where you will transfer a call to park it. Default is set to 70.
4. Choose the number of parking lot spaces to configure. E.g. if 70 is the extension and 8 slots are configured, the parking slots will be 71-78.
5. Choose the timeout period that a parked call will attempt to ring back the original parker if not answered.

6. Choose the destination of the parked call if the call is not picked up from the parking stall.
7. Click Submit
8. Click "Apply Configuration Changes"
9. Click "Continue with Reload"

